



Sun Enterprise 10000 Capacity on Demand 1.0 Reference Manual

Sun Microsystems, Inc.
901 San Antonio Road
Palo Alto, CA 94303-4900
U.S.A.

Part No: 806-2191-10
October 1999, Revision A

Copyright 1999 Sun Microsystems, Inc. 901 San Antonio Road, Palo Alto, California 94303-4900 U.S.A. All rights reserved.

This product or document is protected by copyright and distributed under licenses restricting its use, copying, distribution, and decompilation. No part of this product or document may be reproduced in any form by any means without prior written authorization of Sun and its licensors, if any. Third-party software, including font technology, is copyrighted and licensed from Sun suppliers.

Parts of the product may be derived from Berkeley BSD systems, licensed from the University of California. UNIX is a registered trademark in the U.S. and other countries, exclusively licensed through X/Open Company, Ltd.

Sun, Sun Microsystems, the Sun logo, SunDocs, Java, the Java Coffee Cup logo, and Solaris are trademarks, registered trademarks, or service marks of Sun Microsystems, Inc. in the U.S. and other countries. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. in the U.S. and other countries. Products bearing SPARC trademarks are based upon an architecture developed by Sun Microsystems, Inc.

The OPEN LOOK and Sun™ Graphical User Interface was developed by Sun Microsystems, Inc. for its users and licensees. Sun acknowledges the pioneering efforts of Xerox in researching and developing the concept of visual or graphical user interfaces for the computer industry. Sun holds a non-exclusive license from Xerox to the Xerox Graphical User Interface, which license also covers Sun's licensees who implement OPEN LOOK GUIs and otherwise comply with Sun's written license agreements.

RESTRICTED RIGHTS: Use, duplication, or disclosure by the U.S. Government is subject to restrictions of FAR 52.227-14(g)(2)(6/87) and FAR 52.227-19(6/87), or DFAR 252.227-7015(b)(6/95) and DFAR 227.7202-3(a).

DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID.

Copyright 1999 Sun Microsystems, Inc. 901 San Antonio Road, Palo Alto, California 94303-4900 Etats-Unis. Tous droits réservés.

Ce produit ou document est protégé par un copyright et distribué avec des licences qui en restreignent l'utilisation, la copie, la distribution, et la décompilation. Aucune partie de ce produit ou document ne peut être reproduite sous aucune forme, par quelque moyen que ce soit, sans l'autorisation préalable et écrite de Sun et de ses bailleurs de licence, s'il y en a. Le logiciel détenu par des tiers, et qui comprend la technologie relative aux polices de caractères, est protégé par un copyright et licencié par des fournisseurs de Sun.

Des parties de ce produit pourront être dérivées du système Berkeley BSD licenciés par l'Université de Californie. UNIX est une marque déposée aux Etats-Unis et dans d'autres pays et licenciée exclusivement par X/Open Company, Ltd.

Sun, Sun Microsystems, le logo Sun, SunDocs, Java, le logo Java Coffee Cup, et Solaris sont des marques de fabrique ou des marques déposées, ou marques de service, de Sun Microsystems, Inc. aux Etats-Unis et dans d'autres pays. Toutes les marques SPARC sont utilisées sous licence et sont des marques de fabrique ou des marques déposées de SPARC International, Inc. aux Etats-Unis et dans d'autres pays. Les produits portant les marques SPARC sont basés sur une architecture développée par Sun Microsystems, Inc.

L'interface d'utilisation graphique OPEN LOOK et Sun™ a été développée par Sun Microsystems, Inc. pour ses utilisateurs et licenciés. Sun reconnaît les efforts de pionniers de Xerox pour la recherche et le développement du concept des interfaces d'utilisation visuelle ou graphique pour l'industrie de l'informatique. Sun détient une licence non exclusive de Xerox sur l'interface d'utilisation graphique Xerox, cette licence couvrant également les licenciés de Sun qui mettent en place l'interface d'utilisation graphique OPEN LOOK et qui en outre se conforment aux licences écrites de Sun.

CETTE PUBLICATION EST FOURNIE "EN L'ETAT" ET AUCUNE GARANTIE, EXPRESSE OU IMPLICITE, N'EST ACCORDEE, Y COMPRIS DES GARANTIES CONCERNANT LA VALEUR MARCHANDE, L'APTITUDE DE LA PUBLICATION A REpondre A UNE UTILISATION PARTICULIERE, OU LE FAIT QU'ELLE NE SOIT PAS CONTREFAISANTE DE PRODUIT DE TIERS. CE DENI DE GARANTIE NE S'APPLIQUERAIT PAS, DANS LA MESURE OU IL SERAIT TENU JURIDIQUEMENT NUL ET NON AVENU.



Please
Recycle

Sun Enterprise 10000 SSP Attributions:

This software is copyrighted by the Regents of the University of California, Sun Microsystems, Inc., and other parties. The following terms apply to all files associated with the software unless explicitly disclaimed in individual files.

The authors hereby grant permission to use, copy, modify, distribute, and license this software and its documentation for any purpose, provided that existing copyright notices are retained in all copies and that this notice is included verbatim in any distributions. No written agreement, license, or royalty fee is required for any of the authorized uses. Modifications to this software may be copyrighted by their authors and need not follow the licensing terms described here, provided that the new terms are clearly indicated on the first page of each file where they apply.

IN NO EVENT SHALL THE AUTHORS OR DISTRIBUTORS BE LIABLE TO ANY PARTY FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OF THIS SOFTWARE, ITS DOCUMENTATION, OR ANY DERIVATIVES THEREOF, EVEN IF THE AUTHORS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

THE AUTHORS AND DISTRIBUTORS SPECIFICALLY DISCLAIM ANY WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT. THIS SOFTWARE IS PROVIDED ON AN "AS IS" BASIS, AND THE AUTHORS AND DISTRIBUTORS HAVE NO OBLIGATION TO PROVIDE MAINTENANCE, SUPPORT, UPDATES, ENHANCEMENTS, OR MODIFICATIONS.

RESTRICTED RIGHTS: Use, duplication or disclosure by the government is subject to the restrictions as set forth in subparagraph (c) (1) (ii) of the Rights in Technical Data and Computer Software Clause as DFARS 252.227-7013 and FAR 52.227-19.

This is scotty, a simple tcl interpreter with some special commands to get information about TCP/IP networks. Copyright (c) 1993, 1994, 1995, J. Schoenwaelder, TU Braunschweig, Germany, Institute for Operating Systems and Computer Networks. Permission to use, copy, modify, and distribute this software and its documentation for any purpose and without fee is hereby granted, provided that this copyright notice appears in all copies. The University of Braunschweig makes no representations about the suitability of this software for any purpose. It is provided "as is" without express or implied warranty.

Contents

Intro(1M)	2
codcheck(1M)	3
codd(1M)	5
codlit(1M)	7
codsendlog(1M)	8
Intro(4)	10
cod_resource(4)	11

Maintenance Commands

NAME	Intro – Sun Enterprise 10000 Capacity on Demand 1.0 administration								
DESCRIPTION	This section describes commands, scripts, and programs executed in the Sun Enterprise 10000 Capacity on Demand Environment. SSP 3.1.1 is the first release of the SSP software that supports Sun Enterprise 10000 Capacity on Demand 1.0.								
LIST OF COMMANDS	<table><tr><td>codcheck(1M)</td><td>verify that the Capacity on Demand secure log is valid</td></tr><tr><td>codd(1M)</td><td>Capacity on Demand daemon</td></tr><tr><td>codlit(1M)</td><td>install Capacity on Demand license key files</td></tr><tr><td>codsendlog(1M)</td><td>send the Capacity on Demand secure log file to Sun Microsystems</td></tr></table>	codcheck(1M)	verify that the Capacity on Demand secure log is valid	codd(1M)	Capacity on Demand daemon	codlit(1M)	install Capacity on Demand license key files	codsendlog(1M)	send the Capacity on Demand secure log file to Sun Microsystems
codcheck(1M)	verify that the Capacity on Demand secure log is valid								
codd(1M)	Capacity on Demand daemon								
codlit(1M)	install Capacity on Demand license key files								
codsendlog(1M)	send the Capacity on Demand secure log file to Sun Microsystems								

NAME	codcheck – verify that the Capacity on Demand secure log files are valid.
SYNOPSIS	codcheck [-h] [<i>files</i>]
CAUTION	Do not execute this command. It is for the exclusive use of Sun Service personnel or service providers.
DESCRIPTION	<p>The <code>codcheck</code> utility checks that the Capacity on Demand secure log files have not been corrupted. By default, <code>codcheck</code> checks all the secure log files in the <code>/var/opt/SUNWssp/adm</code> directory. If you specify one or more filenames on the command line, only those log files are checked.</p> <p><code>codcheck</code> writes the name of each file it checks to <code>stdout</code>, along with an indication of whether the file is valid or not.</p>
OPTIONS	<p><code>-h</code> Display command line usage information.</p> <p><i>files</i> One or more Capacity on Demand secure log filenames, separated by spaces.</p>
RETURN VALUES	Upon successful completion <code>codcheck</code> returns a zero value; otherwise, it returns a non-zero value.
EXAMPLES	<p>EXAMPLE 1</p> <p>The following example shows the usage information displayed by the <code>-h</code> option:</p> <pre>\$ codcheck -h COD Secure Log Checker (codcheck) Usage: codcheck [-h] [<i>files</i>] Where: <i>files</i> are one or more COD log files to check. -h Displays this help message and exits</pre> <p>EXAMPLE 2</p> <p>In this example, one file is specified on the command line:</p> <pre>\$ codcheck \$SSPLOGGER/cod.log Checking file /var/opt/SUNWssp/adm/cod.log . . . OK</pre> <p>EXAMPLE 3</p> <p>This example shows the default behavior of <code>codcheck</code>:</p> <pre>\$ codcheck Checking file /var/opt/SUNWssp/adm/cod.log . . . OK</pre>


```
Checking file /var/opt/SUNWssp/adm/cod.log.0 . . . OK
Checking file /var/opt/SUNWssp/adm/cod.log.1 . . . Invalid (line 1)
Checking file /var/opt/SUNWssp/adm/cod.log.2 . . . Invalid (line 1)
Checking file /var/opt/SUNWssp/adm/cod.log.3 . . . Invalid (line 1)
Checking file /var/opt/SUNWssp/adm/cod.log.4 . . . Invalid (line 1)
Checking file /var/opt/SUNWssp/adm/cod.log.5 . . . Invalid (line 1)
```

FILES

codcheck uses the following files:

/var/opt/SUNWssp/adm/cod.log

The Capacity on Demand secure log file.

/var/opt/SUNWssp/adm/cod.log.[0-12]

Archived secure log files.

SEE ALSO

codd(1M)

Sun Enterprise 10000 Capacity on Demand 1.0 Administrator Guide

Sun Enterprise 10000 SSP 3.1.1 User Guide

NAME	codd – Sun Enterprise 10000 Capacity on Demand daemon
SYNOPSIS	codd
CAUTION	Do not execute this command manually. It is automatically invoked and monitored for restart by the SSP startup script.
DESCRIPTION	<p>The Capacity on Demand daemon is a process that runs in the background on the SSP that verifies that the resources being used on the Capacity on Demand system are in agreement with the licenses found in the license file.</p> <p>If the license file validation fails or the number of processors in use exceeds the number of processor licenses, <code>codd</code> sends a warning message to the following:</p> <ul style="list-style-type: none"> ■ The platform messages file on the SSP (<code>/var/opt/SUNWssp/adm/messages</code>) ■ The system log file on the SSP (<code>/var/adm/messages</code>) ■ The secure Capacity on Demand log file (<code>/var/opt/SUNWssp/adm/cod.log</code>) ■ The <code>/etc/motd</code> file on the SSP. ■ The <code>ssp</code> user as an email message, and to any other users listed in the <code>/var/opt/SUNWssp/.ssp_private/cod_resource</code> file. ■ All users logged in to the SSP (sent by using <code>wall(1M)</code>). <p><code>codd</code> generates warning messages until the number of processors in use is the same as, or less than, the number of processor licenses.</p> <p>The Capacity on Demand daemon performs the following license validation checks when it is started:</p> <ul style="list-style-type: none"> ■ Verifies that the license file exists ■ Verifies that the license file has not been modified ■ Verifies that all licenses listed in the license file are valid for this host ■ Verifies that the number of processors in use does not exceed the number of licenses <p>After <code>codd</code> starts, it runs until the SSP is shutdown or switched over to the spare SSP, performing license validation checks at regular intervals.</p>
FILES	<p><code>codd</code> uses the following files:</p> <p><code>/var/opt/SUNWssp/.ssp_private/SUNWcod.lic</code></p>

Contains Capacity on Demand license keys.

`/var/opt/SUNWssp/adm/cod.log`

The secure Capacity on Demand log file.

`/var/opt/SUNWssp/.ssp_private/cod_resource`

The Capacity on Demand resource file.

SEE ALSO

`codlit(1M)`, `cod_resource(4)`

Sun Enterprise 10000 Capacity on Demand 1.0 Administrator Guide

Sun Enterprise 10000 SSP 3.1.1 User Guide

NAME	codlit – install Capacity on Demand license keys
SYNOPSIS	codlit [-h] <i>files</i>
DESCRIPTION	<p>codlit installs Capacity on Demand license keys in the license file. Before running this command, you must obtain license keys from your sales representative (see the <i>Sun Enterprise 10000 Capacity on Demand 1.0 Administrator Guide</i>) and copy the license keys to the SSP.</p> <p>codlit performs validity checks on the existing license file, as well as license key files (the same validity checks that are performed by <code>codd(1M)</code>). Any error messages that result from these validity checks are written to standard error.</p> <p>codlit does not install a license in the following situations:</p> <ul style="list-style-type: none"> ■ The license is a duplicate of a line already in the license file. ■ The license is expired. ■ The license is in the wrong tier class. ■ The license has an incorrect host ID. ■ The license has a signature code that does not match the license line. ■ The license is at a tier level for which the tier prerequisites have not been satisfied.
OPTIONS	<p>The following options are supported:</p> <p>-h Display command line usage information.</p> <p><i>files</i> One or more license key filenames, separated by white space.</p>
RETURN VALUES	Upon successful completion <code>codlit</code> returns a zero value; otherwise, it returns a non-zero value.
EXAMPLES	<p>EXAMPLE 1</p> <p>The following example shows the message <code>codlit</code> displays for each license key file:</p> <pre>ssp% codlit file codlit: x license key(s) installed from file, file</pre>
SEE ALSO	<p><code>codd(1M)</code></p> <p><i>Sun Enterprise 10000 Capacity on Demand 1.0 Administrator Guide</i></p> <p><i>Sun Enterprise 10000 SSP 3.1.1 User Guide</i></p>

NAME	<code>codsendlog</code> – send the Capacity on Demand secure log file to Sun Microsystems
SYNOPSIS	codsendlog [-h] [monthly]
CAUTION	Do not execute this command. It is for the exclusive use of Sun Service personnel or service providers.
DESCRIPTION	<p><code>codsendlog</code> sends an email message to Sun Microsystems that contains the Capacity on Demand secure log file.</p> <p>The address to which the email is sent is specified by the <code>SunAddr</code> resource in the <code>cod_resource(4)</code> file. If the <code>SunAddr</code> resource is missing, email is sent to <code>COD_lic@sun.com</code>.</p>
OPTIONS	<p>The following options are supported:</p> <p><code>-h</code> Display command line usage information.</p> <p><code>monthly</code> Do not use this parameter; it is used only by the log rotation utility that is started by <code>cron(1M)</code> each month.</p>
RETURN VALUES	Upon successful completion <code>codsendlog</code> returns a zero value; otherwise, it returns a non-zero value.
SEE ALSO	<p><code>codd(1M)</code>, <code>cod_resource(4)</code></p> <p><i>Sun Enterprise 10000 Capacity on Demand 1.0 Administrator Guide</i></p> <p><i>Sun Enterprise 10000 SSP 3.1.1 User Guide</i></p>

Capacity on Demand 1.0 File Formats

NAME	Intro – Capacity on Demand 1.0 files.
DESCRIPTION	This section contains man pages for Capacity on Demand configuration files.
LIST OF FILES	<code>cod_resource(4)</code> Capacity on Demand resource file

NAME	cod_resource – Capacity on Demand resource file
DESCRIPTION	<p>The <code>cod_resource</code> file contains Capacity on Demand resource information. This file is read by the Capacity on Demand daemon, <code>codd(1M)</code>, when it is started, and by <code>codsendlog(1M)</code> when it is invoked.</p> <p>The resources in the <code>cod_resource</code> file have the following format:</p> <pre>resource_name:resource_value</pre> <p>where <i>resource_name</i> is the name of the resource and <i>resource_value</i> is the value for the resource. Each resource name can only occur once in the <code>cod_resource</code> file. Resource names are case sensitive.</p> <p>The <code>LicenseNotifyList</code> resource lists user names to which email violation notifications are sent. In the default <code>cod_resource</code> file, <code>LicenseNotifyList</code> contains the <code>ssp</code> user. Removing the <code>ssp</code> user from the <code>LicenseNotifyList</code> resource (or removing the <code>LicenseNotifyList</code> resource from this file) has no effect; email violation messages are still sent to the <code>ssp</code> user. You can add additional email addresses to the <code>cod_resource</code> file by editing the file with a text editor. The value of <code>LicenseNotifyList</code> is a list of email addresses separated by spaces. For example:</p> <pre>LicenseNotifyList:ssp root</pre> <p>The <code>SunAddr</code> resource specifies the email address at Sun Microsystems to which the secure log file is sent each month. You can customize this address as needed by editing the <code>cod_resource</code> file with a text editor. For example, you might need to add additional address information required to send email external to your site. If you remove the <code>SunAddr</code> resource from this file, the secure log file will be sent to <code>COD_lic@sun.com</code> (the default email address).</p> <p>The default <code>cod_resource</code> file contains the following:</p> <pre>LicenseNotifyList:ssp SunAddr:COD_lic@sun.com</pre> <p>If you modify the <code>cod_resource</code> file, you must stop and restart the SSP, as follows:</p> <pre>ssp# /etc/init.d/ssp stop ssp# /etc/init.d/ssp start</pre>
FILES	<p>The following file is supported:</p> <pre>\$\$SSPVAR/.ssp_private/cod_resource</pre>
SEE ALSO	<code>codd(1M)</code>